

Shaded entries are unidentified										0,125		
410		Throttle connecting spindle (between carb	Bolts	4	AUC2669					4		BA
411		Throttle connecting spindle (between carb	Plain washers	4	AUC2673					4	BA	
412		Throttle connecting spindle (between carb	Nuts	4	AUC4612					4		BA
		For a BN2								4,576		
1		Front cover for water gallery	Studs for cover	3	2K 3405					1/4"		
2		Front cover for water gallery	Nuts for studs	3	2K 3975					1/4"		BSF
3		Front cover for water gallery	Spring washers	3	2K 1210					1/4"		
9		front cover with oil catcher and felt	Setscrews, cover to engine front plate	5	2K 6208			Hex setscrew		1/4"		
10		front cover with oil catcher and felt	Plain washers	5	2K 5197			oval washer		1/4"		
11		front cover with oil catcher and felt	Spring washers	5	2K 1210					1/4"		
14		Cylinder side cover	Setscrews, long	14	2K 6212			Hex setscrew		1/4"		
15		Cylinder side cover	Setscrew, short	1	2K 3046			Hex setscrew		1/4"		
16		Cylinder side cover	Fibre washers	15	2K 4974				Fiber	1/4"		
17		Crankcase vent pipe with flange and clip	Setscrews to side cover	2	2K 3046			Hex setscrew		1/4"		
18		Crankcase vent pipe with flange and clip	Spring washers	2	2K 1210					1/4"		
57		Bottom cover with suction pipe	Setscrews	4	2K 3060			Hex setscrew		1/4"		
58		Bottom cover with suction pipe	Spring washers	4	2K 5894					1/4"		
63		Oil reservoir (pan)	Nut for screw	1	2K 3975					1/4"		BSF
64		Oil reservoir (pan)	Spring washer	1	2K 5894					1/4"		
87		Balance pipe	Washers for studs	4	2K 1202					1/4"		
88		Balance pipe	Nuts for studs	4	2K 3975					1/4"		BSF
113		Fan	Setscrews	4	2K 3050			Hex setscrew		1/4"		BSF???
114		Fan	Spring washers	4	2K 5894					1/4"		
115		Petrol pump	Setscrews to body	2	6K 9431			Hex setscrew		1/4"		
116		Petrol pump	Spring washers	2	2K 5894					1/4"		
136		Ignition coil	Setscrews, coil to crankcase	2	2K 3046			Hex setscrew		1/4"		
137		Ignition coil	Spring washers	2	2K 5894					1/4"		
153		Distributor with vacuum control	Plain washer for screw	1	PWN 104			Standard flat washer	Plain		Standard washer, standard	1/4"
154		Distributor with vacuum control	Spring washer for screw	1	2K 5894					1/4"		
157		Driving spindle for distributor	Spring washer	1	2K 5894					1/4"		
177	Front	Horn	Bolts. horn to bracket	4	HNS0406			Hex screw	Plain	1/4"	3/4"	UNF
178	Front	Horn	Spring washers	4	LWN 204			Spring Washer	Plain	1/4"		Medium weight spring wash
179	Front	Horn	Bolts. horn to cross member	4	HZS0405			Hex screw	Zinc	1/4"	5/8"	UNF
180	Front	Horn	Spring washers	4	LWZ 104			Spring Washer	Zinc	1/4"		Spring washer, heavy sectio
198	Bulkhead	Flasher unit	Screw to dash	1	PMZ0408			Pan-head screw	Zinc	1/4"	1/2"	UNF
199	Bulkhead	Flasher unit	Washer	1	PWZ 104			Standard flat washer	Zinc	1/4"		Standard washer, standard
200	Bulkhead	Flasher unit	Spring washer	1	LWZ 204			Spring Washer	Zinc	1/4"		Medium weight spring wash
220		Change speed cover	Studs	3	52K 462			Stud		1/4"		UNF
221		Change speed cover	Nuts for studs	3	FNZ 104			None-Lock nut	Zinc	1/4"		Normal thickness & Strengt
222		Change speed cover	Spring washers	3	LWZ 104			Spring Washer	Zinc	1/4"		Spring washer, heavy sectio
232		Solenoid lever	Bolt, lever to shaft	1	HNS0406			Hex screw	Plain	1/4"	3/4"	UNF
233		Solenoid lever	Nut for bolt	1	FNN 104			None-Lock nut	Plain	1/4"		Normal thickness & Strengt
234		Solenoid lever	Spring washer	1	LWN 204			Spring Washer	Plain	1/4"		Medium weight spring wash
241		Clutch thrust ring assembly with pins	Nuts for pins	4	FNN 104			None-Lock nut	Plain	1/4"		Normal thickness & Strengt
242		Rear casing with studs	Studs (1 5/8" long), in casing, for overdrive body	4	7H 5834			Stud		1/4"	1 5/8"	UNF
243		Rear casing with studs	Studs (1 15/16" long), in front casing, for rear casing	2	7H 5833			Stud		1/4"	1 15/16"	UNF
244		Rear casing with studs	Nuts for studs	6	FNN 104			None-Lock nut	Plain	1/4"		Normal thickness & Strengt
245		Rear casing with studs	Spring washers	6	LWN 204			Spring Washer	Plain	1/4"		Medium weight spring wash
257		Rebound rubber	Setscrews to gearbox rear cover	2	HZS0405			Hex setscrew	Zinc	1/4"	5/8"	UNF
258		Rebound rubber	Spring washers	2	LWZ 104			Spring Washer	Zinc	1/4"		Spring washer, heavy sectio
276		Differential shafts	Screws, shafts to hubs	2	CMZ0408			Countersunk	Zinc	1/4"	1/2"	Philips
290		Steering column steady clamp halves	Spring washer	1	2K 5894					1/4"		
291		Steering column steady clamp halves	Bolt. long, for clamp	1	HBZ0422			Hex bolt	Zinc	1/4"	2 3/4"	UNF
327		Rebound buffers (small)	Setscrews to frame	4	HZS0405			Hex setscrew	Zinc	1/4"	5/8"	UNF
328		Rebound buffers (small)	Spring washers	4	LWN 104			Spring Washer	Plain	1/4"		Spring washer, heavy sectio
329		Fulcrum pins, outer, links to swivel axles	Nuts for cotters, U.N.F	2	FNN 104			None-Lock nut	Plain	1/4"		Normal thickness & Strengt
330		Fulcrum pins, outer, links to swivel axles	Spring washers	2	LWN 204			Spring Washer	Plain	1/4"		Medium weight spring wash
350		Wheel cylinder assemblies	Nuts, cylinders to backplates	8	52K 301					1/4"		
351		Wheel cylinder assemblies	Spring washers	8	2K 1210					1/4"		
355		Brackets for front brake hoses	Bolts, brackets to frame	2	HZS0406			Hex screw	Zinc	1/4"	3/4"	UNF
356		Brackets for front brake hoses	Nuts for bolts	2	FNZ 104			None-Lock nut	Zinc	1/4"		Normal thickness & Strengt
357		Brackets for front brake hoses	Spring washers	2	LWZ 204			Spring Washer	Zinc	1/4"		Medium weight spring wash
358		5-way connection for brake pipes, front	Setscrew, 5-way connection to boss	1	HBZ0410			Hex bolt	Zinc	1/4"	1 1/4"	UNF

359	5-way connection for brake pipes, front	Spring washer	1	2K 5894						1/4"		
365	Brake pipe, 3-way connection on rear axle	Setscrew. clip to boss	1	HZS0404	Hex setscrew	Zinc				1/4"	1/2"	UNF
366	Brake pipe, 3-way connection on rear axle	Spring washer	1	LWZ 104	Spring Washer	Zinc			Spring washer, heavy section	1/4"		
368	Rear springs	Nuts for bolts	2	FNZ 104	None-Lock nut	Zinc			Normal thickness & Strength	1/4"		UNF
376	Brackets for bumpers (on body)	Bolts. brackets to body	8	HZS0404	Hex screw	Zinc				1/4"	1/2"	UNF
377	Brackets for bumpers (on body)	Nuts for bolts	8	FNZ 104	None-Lock nut	Zinc			Normal thickness & Strength	1/4"		UNF
378	Brackets for bumpers (on body)	Spring washers	8	LWZ 204	Spring Washer	Zinc			Medium weight spring washer	1/4"		
379	Brackets for bumpers (on body)	Washers	8	PWZ 104	Standard flat washer	Zinc			Standard washer, standard	1/4"		
394	Lever for accelerator pedal shaft	Clamp bolt for lever	1	HZS0408	Hex screw	Zinc				1/4"	1"	UNF
395	Lever for accelerator pedal shaft	Nut	1	FNZ 104	None-Lock nut	Zinc			Normal thickness & Strength	1/4"		UNF
396	Lever for accelerator pedal shaft	Washer	1	PWZ 104	Standard flat washer	Zinc			Standard washer, standard	1/4"		
416	Clutch pedal pad	Bolts, pedal pad to pedal	2	52K 2019						1/4"	1"	UNF
417	Clutch pedal pad	Nuts for bolts	2	52K 301						1/4"		UNF
418	Clutch pedal pad	Spring washers	2	2K 5894						1/4"		
439	Clutch withdrawal fork	Nuts	2	2K 3975						1/4"		BSF
440	Clutch withdrawal fork	Spring washers	2	LWN 204	Spring Washer	Plain			Medium weight spring washer	1/4"		
441	Brake pedal pad	Bolts, pedal pad to pedal	2	52K 2019						1/4"	1"	UNF
442	Brake pedal pad	Nuts for bolts	2	52K 301						1/4"		UNF
443	Brake pedal pad	Spring washers	2	2K 5894						1/4"		
448	Bracket for tank, L.H. Steering	Bolts, tank to bracket	2	HZS0404	Hex screw	Zinc				1/4"	1/2"	UNF
449	Bracket for tank, L.H. Steering	Nuts for bolts	2	FNZ 104	None-Lock nut	Zinc			Normal thickness & Strength	1/4"		UNF
450	Bracket for tank, L.H. Steering	Spring washers	2	2K 5894						1/4"		
453	Fork for cable, balance lever end	Locknut for fork	1	FNZ 204	None-Lock nut	Zinc			Lock nut, half thickness, no	1/4"		UNF
466	Radiator with filler cap	Washers	2	PWZ 204	Standard flat washer	Zinc			Standard washer, large dia	1/4"		
467	Radiator with filler cap	Spring washers	2	LWZ 104	Spring Washer	Zinc			Spring washer, heavy section	1/4"		
468	Radiator with filler cap	Bolts, radiator to top fixing brackets	2	HZS0406	Hex screw	Zinc				1/4"	3/4"	UNF
469	Radiator with filler cap	Nuts for bolts	2	FNZ 104	None-Lock nut	Zinc			Normal thickness & Strength	1/4"		UNF
470	Radiator with filler cap	Washers	2	PWZ 104	Standard flat washer	Zinc			Standard washer, standard	1/4"		
471	Radiator with filler cap	Spring washers	2	LWZ 204	Spring Washer	Zinc			Medium weight spring washer	1/4"		
486	Front wing assembly, L&R	Screws	4	HNS0407	Hex screw	Plain				1/4"	7/8"	UNF
487	Front wing assembly, L&R	Square nuts for cages	4	52K 323	None-Lock nut	Plain				1/4"		UNF
488	Front wing assembly, L&R	Spring washers	4	LWN 204	Spring Washer	Plain			Medium weight spring washer	1/4"		
489	Front apron panel	Screws, 1/4" x 5/8" U.N.F., panel to chassis	4	HZS0406	Hex screw	Zinc				1/4"	3/4"	UNF
490	Front apron panel	Washers	4	PWZ 104	Standard flat washer	Zinc			Standard washer, standard	1/4"		
491	Front apron panel	Spring washers	4	LWN 204	Spring Washer	Plain			Medium weight spring washer	1/4"		
502	Hinge, L&R	Nuts. hinge to boot lid	4	53K 1661	None-Lock nut	Zinc				1/4"		
503	Hinge, L&R	Plain washers	4	PWZ 104	Standard flat washer	Zinc			Standard washer, standard	1/4"		
512	Boot stay	Screws to wheel arch panel	2	HBZ0409	Hex bolt	Zinc				1/4"	1 1/8"	UNF
513	Boot stay	Nuts	2	FNZ 104	None-Lock nut	Zinc			Normal thickness & Strength	1/4"		UNF
514	Boot stay	Spring washers	2	2K 1219	Spring washer	Zinc				1/4"		
515	Boot stay	Plain washers, 1/4"	2	PWZ 104	Standard flat washer	Zinc			Standard washer, standard	1/4"		
532	Hood toggle fastener assembly, L&R	Screws, 1/4" B.S.F.	4	6K 9667						1/4"		BSF
537	Hinges	Screws	4	HBN0408	Hex bolt	Plain				1/4"	1"	UNF
538	Hinges	Plain washers	4	PWN 104	Standard flat washer	Plain			Standard washer, standard	1/4"		
539	Hinges	Spring washers	4	2K 1210						1/4"		
590	Passanger seat: Packers to seats	Nuts fixed to base packers	4	14B 2876						1/4"		UNF
591	Passanger seat: Packers to seats	Bolts, 1" for passenger seat	4	HBZ0408	Hex bolt	Zinc				1/4"	1"	UNF
592	Passanger seat: Packers to seats	Plain washers. small	4	PWZ 104	Standard flat washer	Zinc			Standard washer, standard	1/4"		
593	Passanger seat: Packers to floor	Bolts. 1.25": base, packer and washer plate to floor	6	HBZ0410	Hex bolt	Zinc				1/4"	1 1/4"	UNF
594	Passanger seat: Packers to floor	Plain washers, small	6	PWZ 104	Standard flat washer	Zinc			Standard washer, standard	1/4"		
595	Passanger seat: Packers to floor	Plain washers	3	PWZ 204	Standard flat washer	Zinc			Standard washer, large dia	1/4"		
596	Passanger seat: Packers to floor	D washers	3	2K 9993	D-WASHER-for bolts					1/4"		
597	Passanger seat: Packers to floor	Spring washers	6	LWZ 104	Spring Washer	Zinc			Spring washer, heavy section	1/4"		
598	Passanger seat: Packers to floor	Nuts	6	FNZ 104	None-Lock nut	Zinc			Normal thickness & Strength	1/4"		UNF
599	Driver Seat: seat base to slides	Nuts, seat slides to seat base panels	6	FNZ 104	None-Lock nut	Zinc			Normal thickness & Strength	1/4"		UNF
600	Driver Seat: seat base to slides	Plain washers	6	PWZ 204	Standard flat washer	Zinc			Standard washer, large dia	1/4"		
601	Driver Seat: seat base to slides	Spring washers	6	LWN 204	Spring Washer	Plain			Medium weight spring washer	1/4"		
602	Driver seat: slides to floor	Tee nuts, fixing seats and slides to floor	6	14B 2877	Nut (tee nut)					1/4"		UNF
602a	Driver seat: slides to floor	studbolts for teenuts	6		studbolts					1/4"	3/4 or 7/8"	UNF
605	Air (fresh) valve assembly	Plain washers	2	2K 1202						1/4"		
634	Grab handle	Plain washers	2	PWZ 204	Standard flat washer	Zinc			Standard washer, large dia	1/4"		
635	Grab handle	Spring washers	2	LWZ 204	Spring Washer	Zinc			Medium weight spring washer	1/4"		
643	Illumination lamp bracket, rear license plat	Nuts, bracket to rear bumper	2	FNZ 104	None-Lock nut	Zinc			Normal thickness & Strength	1/4"		UNF
644	Illumination lamp bracket, rear license plat	Spring washers	2	LWN 204	Spring Washer	Plain			Medium weight spring washer	1/4"		
645	Illumination lamp bracket, rear license plat	Plain washers	2	PWZ 104	Standard flat washer	Zinc			Standard washer, standard	1/4"		

651	Hinge bracket, bonnet lid, L&R	Screws to hinges	4	53K 2017						1/4"		
652	Hinge bracket, bonnet lid, L&R	Plain washers	4	PWZ 104		Standard flat washer	Zinc		Standard washer, standard	1/4"		
653	Hinge bracket, bonnet lid, L&R	Spring washers	4	2K 1210						1/4"		
654	Hinge bracket, bonnet lid, L&R	Nuts	4	FNZ 104		None-Lock nut	Zinc		Normal thickness & Strengt	1/4"		UNF
667	Windscreen frame assembly	Screws, screen to body	4	53K 2019						1/4"		
668	Windscreen frame assembly	Nuts	4	FNZ 104		None-Lock nut	Zinc		Normal thickness & Strengt	1/4"		UNF
669	Windscreen frame assembly	Plain washers	8	PWZ 104		Standard flat washer	Zinc		Standard washer, standard	1/4"		
670	Windscreen frame assembly	Spring washers	4	2K 1210						1/4"		
680	Rear number plate	Bolts to brackets	2	HZS0404		Hex screw	Zinc			1/4"	1/2"	UNF
681	Rear number plate	Nuts for bolts	2	FNZ 104		None-Lock nut	Zinc		Normal thickness & Strengt	1/4"		UNF
682	Rear number plate	Plain washers	2	PWZ 204		Standard flat washer	Zinc		Standard washer, large dia	1/4"		
683	Rear number plate	Spring washers	2	LWZ 204		Spring Washer	Zinc		Medium weight spring wash	1/4"		
208	Body	Side and blinker lamps, Stop and tail lamp	Washers	12	2K 9161	PWZ 202				2/16"		
209	Body	Side and blinker lamps, Stop and tail lamp	Spring washers	12	6K 53					2/16"		
205	Body	Headlamps	Spring washers	8	2K 1209					3/16"		
211	Body	Rear reflectors	Spring washers	6	2K 8232	LWZ 203				3/16"		
393	Accelerator pedal with shaft, LH Steering	Spring washers	3	2K 1209			Zinc			3/16"		
482	Support bracket, bonnet surround, L&R	Plain washers	8	6K 9695						3/16"		
483	Support bracket, bonnet surround, L&R	Spring washers	4	2K 1209						3/16"		
498	Division panel, radiator to grille	Plain Washers	6	2K 9907						3/16"		
511	Spare wheel breeching staple	Spring washers	2	2K 1209						3/16"		
526	Hood cover retainers (on rear top panel)	Spring washers	4	2K 1209						3/16"		
550	Hinge pillar brackets	Plain washers	4	6K 9695						3/16"		
558	Fascia and instrument panel	Spring washers	4	2K 1209						3/16"		
561	Body side flash	Nuts to wings	6	52K 325		None-Lock nut				3/16"		
562	Body side flash	Plain washers	6	6K 9695						3/16"		
563	Body side flash	Spring washers	6	2K 1209						3/16"		
578	Battery access panel assembly	Screws. battery access panel to axle cover panel	4	51K 2616						3/16"		
579	Battery access panel assembly	Nuts	4	51K 325		None-Lock nut				3/16"		
580	Battery access panel assembly	Plain washers	4	2K 1201						3/16"		
581	Battery access panel assembly	Spring washers	4	2K 1209						3/16"		
657	Bonnet lock support bracket	Plain washers	6	6K 9695						3/16"		
658	Bonnet lock support bracket	Spring washers	3	2K 1209						3/16"		
661	Tension spring retainer for bonnet catch	Plain washers	2	2K 1209						3/16"		
247	Coupling flange	Plain washer for nut	1	PWN 112		Standard flat washer	Plain		Standard washer, standard	3/4"		
274	flange for propeller shaft	Nut, flange to pinion	1	FNZ 612		None-Lock nut	Zinc		Lock nut, half thickness, hig	3/4"		UNF
275	Flange for propeller shaft	Washers	1	LWZ 212		Spring Washer	Zinc		Medium weight spring wash	3/4"		
303	Steering side and cross tube lever for stee	Washer	1	PWZ 112		Standard flat washer	Zinc		Standard washer, standard	3/4"		
12	Engine front plate	Setscrews, front plate to crankcase	5	2K 6562		Hex setscrew				3/8"		
13	Engine front plate	Spring washers	5	2K 5895	LWZ 206					3/8"		
22	Engine rear plate	Setscrews, rear plate to crankcase	8	2K 5946		Hex setscrew				3/8"		
23	Engine rear plate	Spring washers	8	2K 5895	LWZ 206					3/8"		
24	Engine rear plate	Setscrews, rear plate to rear main bearing cap	2	2K 5289		Hex setscrew				3/8"		
28	Engine front support brackets	Bolts to engine front plate	4	2K 8490						3/8"		
29	Engine front support brackets	Nuts for bolts	4	2K 3977		Nut		20TPI		3/8"		BSF
30	Engine front support brackets	Spring washers	4	LWN 106		Spring Washer	Plain		Spring washer, heavy sectio	3/8"		
31	Engine front support brackets	Setscrews, brackets to cran kcase	4	2K 3138		Hex setscrew				3/8"		
32	Engine front support brackets	Spring washers	4	LWN 106		Spring Washer	Plain		Spring washer, heavy sectio	3/8"		
38	Engine mounting bracket extensions	Bolts to frame brackets	8	HZS0608		Hex screw	Zinc			3/8"	1"	UNF
39	Engine mounting bracket extensions	Spring washers	8	LWN 106		Spring Washer	Plain		Spring washer, heavy sectio	3/8"		
52	Connecting rods	Clamping bolts for gudgeon pins	4	2K 5681						3/8"		
53	Connecting rods	Spring washers	4	2K 5895	LWZ 206					3/8"		
70	Valve rocket brackets without tapped hole	Studs in cylinder head, short	4	2K 6349						3/8"		BSF
71	Valve rocket brackets without tapped hole	Studs in cylinder head. long	4	6K 776						3/8"		BSF
72	Valve rocket brackets without tapped hole	Plain washers for studs	8	2K 1204						3/8"		BSF
73	Valve rocket brackets without tapped hole	Nuts for studs	8	2K 3977		Nut		20TPI		3/8"		BSF
74	Valve rocket brackets without tapped hole	Spring washers	8	2K 5895	LWZ 206					3/8"		
83	Cylinder head studs	Studs, in cylinder head, for manifold	2	2K 3494						3/8"		
84	Cylinder head studs	Studs, in cylinder head, for manifold	4	2K 3496						3/8"		
85	Cylinder head studs	Nuts for studs, brass	6	2K 4052						3/8"		
86	Cylinder head studs	Washers for studs	2	2K 1204						3/8"		
107	Water pump assembly	Nut (plain) for stud	1	2K 3977		Nut		20TPI		3/8"		BSF
108	Water pump assembly	Spring washers	3	2K 5863	LWZ 206					3/8"		
121	Carburetter	Nuts for studs-carburetters to adaptors	4	2K 3977		Nut		20TPI		3/8"		BSF
122	Carburetter	Washers for studs	4	2K 1204						3/8"		

127	Adaptor for oil filter	Nuts for bolts	2 2K 3977		Nut			20TPI		3/8"		BSF
128	Adaptor for oil filter	Washers	2 2K 1204							3/8"		
129	Adaptor for oil filter	Bolts, filter to adaptor	2 2K 3175							3/8"		
130	Adaptor for oil filter	Setscrew, long, adaptor to crankcase	1 2K 3151		Hex setscrew					3/8"		
131	Adaptor for oil filter	Setscrew, short, adaptor to crankcase	1 2K 3146		Hex setscrew					3/8"		
132	Adaptor for oil filter	Washers for setscrews	2 2K 1204							3/8"		
150	Adjusting link for dynamo	Nut, 3/8" B.S.F.	1 6K 281							3/8"		BSF
159	Starter	Nuts for bolts...	2 2K 3977		Nut			20TPI		3/8"		BSF
160	Starter	Spring washers	2 2K 5895	LWZ 206						3/8"		
212	Propeller shaft	Bolts for flange to bevel pinion flange	4 53K 1048							3/8"		UNF
213	Propeller shaft	Nuts, nyloc, for bolts U.N.F.	4 LNZ 206		Stiff nut or nyloc	Zinc		Lock nut, half thickness, no		3/8"		UNF
214	Propeller shaft	Spring washers	4 LWZ 106		Spring Washer	Zinc		Spring washer, heavy sectio		3/8"		
259	Engine tie rod	Nuts for tie rod	4 FNZ 206		None-Lock nut	Zinc		Lock nut, half thickness, no		3/8"		UNF
262	Hinge pin	Nut for pin	1 FNZ 106		None-Lock nut	Zinc		Normal thickness & Strengt		3/8"		UNF
263	Hinge pin	Spring washer	1 LWN 106		Spring Washer	Plain		Spring washer, heavy sectio		3/8"		
270	Gear carrier with bearing caps	Nuts for bolts	12 FNZ 106		None-Lock nut	Zinc		Normal thickness & Strengt		3/8"		UNF
271	Gear carrier with bearing caps	Spring washers	12 LWZ 106		Spring Washer	Zinc		Spring washer, heavy sectio		3/8"		
282	Brake backplate	Bolts, backplates to axle	8 ATC7071							3/8"		
283	Brake backplate	Nuts, nyloc, for bolts	8 LNZ 206		Stiff nut or nyloc	Zinc		Lock nut, half thickness, no		3/8"		UNF
286	Adjuster unit assemblies	Nuts adjusters to backplates	4 FNZ 106		None-Lock nut	Zinc		Normal thickness & Strengt		3/8"		UNF
287	Adjuster unit assemblies	Spring washers	4 2K 5863	LWZ 206						3/8"		
297	Steering box clamping and mounting brack	Spring washers	3 2K 5895	LWZ 206						3/8"		
304	Steering idler assembly	Setscrews to chassis frame	3 HBZ0624		Hex bolt	Zinc				3/8"	3"	UNF
305	Steering idler assembly	Spring washers	3 2K 5895	LWZ 206						3/8"		
318	Front shock absorbers	Setscrews, shock absorbers to frame	8 HZS0608		Hex setscrew	Zinc				3/8"	1"	UNF
319	Front shock absorbers	Shakeproof washers	8 LWZ 106		Spring Washer	Zinc		Spring washer, heavy sectio		3/8"		
320	Front shock absorbers	Bolts for arms	2 HBN0620		Hex bolt	Plain				3/8"	2 1/2"	UNF
321	Front shock absorbers	Nuts for bolts	2 FNN 106		None-Lock nut	Plain		Normal thickness & Strengt		3/8"		UNF
322	Front shock absorbers	Spring washers	2 LWN 106		Spring Washer	Plain		Spring washer, heavy sectio		3/8"		
323	Front shock absorbers	Clamping bolts for arms to shaft	2 HBN0616		Hex bolt	Plain				3/8"	2"	UNF
324	Front shock absorbers	Nuts for bolts	2 FNN 106		None-Lock nut	Plain		Normal thickness & Strengt		3/8"		UNF
325	Front shock absorbers	Spring washers	2 LWN 106		Spring Washer	Plain		Spring washer, heavy sectio		3/8"		
333	Spring seats with bumper	Bolts, seats to links	4 HBZ0618		Hex bolt	Zinc				3/8"	2 1/4"	UNF
334	Spring seats with bumper	Bolts, seats and anti-roll bar plates to links	4 HBZ0620		Hex bolt	Zinc				3/8"	2 1/2"	UNF
335	Spring seats with bumper	Nuts for bolts	8 LNZ 106		Stiff nut or nyloc	Zinc		Normal thickness & Strengt		3/8"		UNF
336	Spring seats with bumper	Washers	8 PWZ 106		Standard flat washer	Zinc		Standard washer, standard		3/8"		
337	Spring seats with bumper	Spring washers	8 LWZ 106		Spring Washer	Zinc		Spring washer, heavy sectio		3/8"		
354	Flexible brake hose	Nuts for hoses	3 FNZ 206		None-Lock nut	Zinc		Lock nut, half thickness, no		3/8"		UNF
369	Rear spring clips	Nuts, U.N.F., nyloc	8 LNZ 206		Stiff nut or nyloc	Zinc		Lock nut, half thickness, no		3/8"		UNF
370	Shackle pins, bottom, U.N.F. thread	Locknuts, U.N.F.	4 FNZ 206		None-Lock nut	Zinc		Lock nut, half thickness, no		3/8"		UNF
371	Shackle pins, bottom, U.N.F. thread	Nuts, U.N.F.	2 FNZ 106		None-Lock nut	Zinc		Normal thickness & Strengt		3/8"		UNF
372	Shackle pins, bottom, U.N.F. thread	Spring washers	4 LWZ 206		Spring Washer	Zinc		Medium weight spring wash		3/8"		
380	Rear shock absorber with arm and link	Bolts to frame, U.N.F.	4 HZS0608		Hex screw	Zinc				3/8"	1"	UNF
381	Rear shock absorber with arm and link	Nuts for bolts	4 FNZ 506		None-Lock nut	Zinc		Normal thickess, high stren		3/8"		UNF
382	Rear shock absorber with arm and link	Spring washers	4 LWZ 106		Spring Washer	Zinc		Spring washer, heavy sectio		3/8"		
383	links for shock absorbers	Nuts, links to arms	2 FNZ 106		None-Lock nut	Zinc		Normal thickness & Strengt		3/8"		UNF
384	links for shock absorbers	Spring washers	2 LWZ 106		Spring Washer	Zinc		Spring washer, heavy sectio		3/8"		
387	Rear axle tie rod	Bolts, bracket to axle	2 HZS0607		Hex screw	Zinc				3/8"	7/8"	UNF
388	Rear axle tie rod	Nuts for bolts	2 FNZ 106		None-Lock nut	Zinc		Normal thickness & Strengt		3/8"		UNF
389	Rear axle tie rod	Spring washers	2 LWZ 106		Spring Washer	Zinc		Spring washer, heavy sectio		3/8"		
399	Accelerator relay bellcrank lever	Washer for nut	1 2K 5890							3/8"		
400	Accelerator relay bellcrank lever	Nut, fulcrum pin to dash	1 2K 3977		Nut			20TPI		3/8"		BSF
401	Accelerator relay bellcrank lever	Spring washer for nut	1 2K 5895	LWZ 206						3/8"		
402	Accelerator relay bellcrank lever	Plain washer	1 52K 1343							3/8"		
431	Clutch housing with bushes	Bolts, gearbox to rear plate	5 HBZ0610		Hex bolt	Zinc				3/8"	1 1/4"	UNF
433	Clutch housing with bushes	Nuts for bolts	7 FNZ 106		None-Lock nut	Zinc		Normal thickness & Strengt		3/8"		UNF
434	Clutch housing with bushes	Spring washers	7 LWZ 206		Spring Washer	Zinc		Medium weight spring wash		3/8"		
603	Driver seat: slides to floor	Plain washers	3 PWZ 106		Standard flat washer	Zinc		Standard washer, standard		3/8"		
604	Driver seat: slides to floor	Spring washers	6 LWZ 206		Spring Washer	Zinc		Medium weight spring wash		3/8"		
674	Spring bars, front bumper	Setscrews, spring bars to frame	4 52K 1587		Hex setscrew					3/8"		
675	Spring bars, front bumper	Spring washers	4 LWN 106		Spring Washer	Plain		Spring washer, heavy sectio		3/8"		
676	Spring bars, front bumper	Washers	4 PWN 104	should be	Standard flat washer	Plain		Standard washer, standard		3/8"		
677	Spring bars, rear bumper	Setscrews, spring bars to frame	4 52K 1587		Hex setscrew					3/8"		
678	Spring bars, rear bumper	Spring washers	4 LWN 106		Spring Washer	Plain		Spring washer, heavy sectio		3/8"		
679	Spring bars, rear bumper	Washers	4 PWN 104	should be	Standard flat washer	Plain		Standard washer, standard		3/8"		

7	front cover with oil catcher and felt	Plain washers	7 2K 7440				Oval		5/16"		
8	front cover with oil catcher and felt	Spring washers	7 2K 1211	LWZ205					5/16"		
20	Crankcase vent pipe with flange and clip	Spring washer	1 2K 5319	LWZ 205					5/16"		
25	Engine rear plate	Spring washers	2 LWN 205		Spring Washer	Plain		Medium weight spring wash	5/16"		
27	Engine rear plate	Spring washers	2 2K 5319	LWZ 205					5/16"		
33	Rubber mounting buffers with bolts	Nuts	2 2K 3976		Nut				5/16"		BSF
34	Rubber mounting buffers with bolts	Spring washers	2 2K 5319	LWZ 205					5/16"		
40	Camshaft	Setscrews to crankcase	2 2K 3094		Hex setscrew				5/16"		
41	Camshaft	Spring washers	2 2K 5319	LWZ 205					5/16"		
59	Oil strainer	Nuts	3 2K 3976		Nut				5/16"		BSF
60	Oil strainer	Spring washers	3 2K 5319	LWZ 205					5/16"		
77	Exhaust manifold	Studs for exhaust pipe	3 2K 7708						5/16"		
78	Exhaust manifold	Nuts for studs	3 2K 4051						5/16"		
79	Exhaust manifold	Plain washers	3 PWZ 105		Standard flat washer	Zinc		Standard washer, standard	5/16"		
89	Bracket for exhaust pipe	Nuts for "U" bolt	2 FNZ 105		None-Lock nut	Zinc		Normal thickness & Strengt	5/16"		UNF
90	Bracket for exhaust pipe	Spring washers	2 LWZ 205		Spring Washer	Zinc		Medium weight spring wash	5/16"		
91	Clips for exhaust pipe and tail pipe	Bolts for clips	2 HZS0506		Hex screw	Zinc			5/16"	3/4"	UNF
92	Clips for exhaust pipe and tail pipe	Nuts for bolts	2 FNZ 105		None-Lock nut	Zinc		Normal thickness & Strengt	5/16"		UNF
93	Clips for exhaust pipe and tail pipe	Spring washers	2 LWZ 205		Spring Washer	Zinc		Medium weight spring wash	5/16"		
94	Clips for exhaust pipe and tail pipe	Bolts for mounting	2 PMZ0510		Pan-head screw	Zinc		Philips	5/16"	5/8"	UNF
95	Clips for exhaust pipe and tail pipe	Nuts for bolts	2 FNZ 105		None-Lock nut	Zinc		Normal thickness & Strengt	5/16"		UNF
96	Clips for exhaust pipe and tail pipe	Spring washers	2 LWZ 205		Spring Washer	Zinc		Medium weight spring wash	5/16"		
97	Tail pipe	Bolts, mountings to body	4 HZS0506		Hex screw	Zinc			5/16"	3/4"	UNF
98	Tail pipe	Nuts for bolts	4 FNZ 105		None-Lock nut	Zinc		Normal thickness & Strengt	5/16"		UNF
99	Tail pipe	Spring washers	4 LWZ 205		Spring Washer	Zinc		Medium weight spring wash	5/16"		
100	Water outlet elbow	Studs, pipe to cylinder head	4 2K 3450						5/16"		BSF
101	Water outlet elbow	Nuts for studs	4 2K 3976		Nut				5/16"		BSF
102	Water outlet elbow	Spring washers	4 2K 1211	LWZ205					5/16"		
103	Outlet pipe (copper) with clips	Nuts for studs, heater pipe dips to adaptors	2 2K 3976		Nut				5/16"		BSF
104	Outlet pipe (copper) with clips	Spring washers	2 2K 1211	LWZ205					5/16"		
117	Blanking plate for mechanical petrol pump	Studs in crankcase	2 2K 3451						5/16"		
119	Blanking plate for mechanical petrol pump	Nuts	2 2K 3976		Nut				5/16"		BSF
120	Blanking plate for mechanical petrol pump	Spring washers	2 2K 1211	LWZ205					5/16"		
123	Carburettor shield	Setscrews-shield to manifold	2 2K 6146		Hex setscrew				5/16"		
124	Carburettor shield	Spring washers	2 2K 1211	LWZ205					5/16"		
125	Air cleaner	Setscrews, cleaners to carburetters	4 52K 2035		Hex setscrew				5/16"		
126	Air cleaner	Washers	4 52K 1342	PWZ 105					5/16"		
133	Tachometer drive gear assembly	Setscrew, short. housing to crankcase	1 2K 3100		Hex setscrew				5/16"		
134	Tachometer drive gear assembly	Setscrew. long, housing to crankcase	1 2K 3101		Hex setscrew				5/16"		
135	Tachometer drive gear assembly	Spring washers	2 2K 5319	LWZ 205					5/16"		
142	Dynamo	Nuts for bolts	2 6K 280						5/16"		
143	Dynamo	Spring washers	2 2K 5319	LWZ 205					5/16"		
146	Dynamo bracket	Washers	4 2K 1203						5/16"		
161	Clutch assembly	Screws to flywheel	6 2K 5881						5/16"		
162	Clutch assembly	Spring washers	6 2K 5319	LWZ 205					5/16"		
215	Gearbox casing	Setscrews, gearbox to clutch housing	8 HZS0510		Hex setscrew	Zinc			5/16"	1 1/4"	UNF
216	Gearbox casing	Spring washers	8 LWZ 105		Spring Washer	Zinc		Spring washer, heavy sectio	5/16"		
217	Side cover	Bolts, short	12 HBN0512		Hex bolt	Plain			5/16"	1 1/2"	UNF
218	Side cover	Bolt, long	1 HBN0522		Hex bolt	Plain			5/16"	2 3/4"	UNF
219	Side cover	Spring washers	13 LWZ 205		Spring Washer	Zinc		Medium weight spring wash	5/16"		
223	Overdrive unit with gearbox adaptor (28%)	Studs in gearbox	8 51K 505		Stud				5/16"		UNF
224	Overdrive unit with gearbox adaptor (28%)	Nuts for studs	8 FNN 505		None-Lock nut	Plain		Normal thickness, high stren	5/16"		UNF
225	Overdrive unit with gearbox adaptor (28%)	Spring washers	8 LWN 105		Spring Washer	Plain		Spring washer, heavy sectio	5/16"		
226	Adaptor plate, overdrive unit to gearbox	Nuts for studs	2 FNN 105		None-Lock nut	Plain		Normal thickness & Strengt	5/16"		UNF
227	Adaptor plate, overdrive unit to gearbox	Spring washers	2 LWN 205		Spring Washer	Plain		Medium weight spring wash	5/16"		
228	Front casing assembly	Studs (1/4" long) in case, for adaptor plate	4 7H 5830		Stud				5/16"	1/4"	UNF
229	Front casing assembly	Studs (1" long) in case, for adaptor plate	1 7H 5831		Stud				5/16"	1"	UNF
230	Front casing assembly	Nuts for studs	4 FNN 205		None-Lock nut	Plain		Lock nut, half thickness, no	5/16"		UNF
231	Front casing assembly	Spring washers	4 LWN 205		Spring Washer	Plain		Medium weight spring wash	5/16"		
235	Solenoid bracket and side cover for casing	Studs (1.75" long), in case, for bracket	2 7H 5832		Stud				5/16"	1 3/4"	UNF
236	Solenoid bracket and side cover for casing	Plain washers	2 FNN 105		None-Lock nut	Plain		Normal thickness & Strengt	5/16"		UNF
237	Solenoid bracket and side cover for casing	Spring washers	2 LWN 205		Spring Washer	Plain		Medium weight spring wash	5/16"		
238	Solenoid bracket and side cover for casing	Setscrews (1.75" long), bracket to case	2 7H 5853		Hex setscrew				5/16"	1 3/4"	UNF
239	Solenoid bracket and side cover for casing	Plain washers	2 FNN 105		None-Lock nut	Plain		Normal thickness & Strengt	5/16"		UNF
240	Solenoid bracket and side cover for casing	Spring washers	2 LWN 205		Spring Washer	Plain		Medium weight spring wash	5/16"		

249		Speedometer pinion assembly	Spring washer for screw	1	LWN 205		Spring Washer	Plain		Medium weight spring wash	5/16"		
251	BN2	Mounting bracket, L&R	Setscrews, brackets to frame	6	HZS0506		Hex setscrew	Zinc			5/16"	3/4"	UNF
252		Mounting bracket, L&R	Washers	6	PWZ 105		Standard flat washer	Zinc		Standard washer, standard	5/16"		
253		Mounting bracket, L&R	Spring washers	6	LWZ 205		Spring Washer	Zinc		Medium weight spring wash	5/16"		
254		Rubber mountings	Nuts for mounting bolts	2	FNZ 105		None-Lock nut	Zinc		Normal thickness & Strengt	5/16"		UNF
255		Rubber mountings	Bolts, rubber mountings to frame	4	HZS0506		Hex screw	Zinc			5/16"	3/4"	UNF
256		Rubber mountings	Spring washers	6	LWZ 205		Spring Washer	Zinc		Medium weight spring wash	5/16"		
284		Brake backplate	Steady posts	4	7H 4461						5/16"		UNF
285		Brake backplate	Nuts, 5/16" U.N.F., for steady posts	4	7H 4991						5/16"		UNF
293		Steering column steady clamp halves	Spring washer	1	2K 5319	LWZ 205					5/16"		
298	late BN2	Side cover plate	Setscrews. 5/16" U.N.F.	4	7H 6434		Hex setscrew				5/16"		UNF
299		Side cover plate	Spring washers	4	LWZ 105		Spring Washer	Zinc		Spring washer, heavy sectio	5/16"		
300		End cover with adaptor	Setscrews. 5/16" U.N.F.	4	7H 6434		Hex setscrew				5/16"		UNF
301		End cover with adaptor	Spring washers	4	LWZ 105		Spring Washer	Zinc		Spring washer, heavy sectio	5/16"		
306		Cover for body	Setscrews, cover to body	3	HZS0506		Hex setscrew	Zinc			5/16"	3/4"	UNF
307		Cover for body	Spring washers	3	LWZ 105		Spring Washer	Zinc		Spring washer, heavy sectio	5/16"		
338		Bumpers (large) with bolts	Nuts for bolts	4	FNZ 105		None-Lock nut	Zinc		Normal thickness & Strengt	5/16"		UNF
339		Bumpers (large) with bolts	Spring washers	4	2K 5319	LWZ 205					5/16"		
340		Anti-roiil bar links	Nuts for links	4	LNZ 305		Stiff nut or nyloc	Zinc		Castle nut, extra thick, norm	5/16"		UNF
342		Anti-roll bar	Spring washers	4	2K 5319	LWZ 205					5/16"		
360		Bracket on axle for 3-way connection	Setscrew, U.N.F. bracket to axle	1	HZS0505		Hex setscrew	Zinc			5/16"	5/8"	UNF
361		Bracket on axle for 3-way connection	Spring washer	1	LWZ 105		Spring Washer	Zinc		Spring washer, heavy sectio	5/16"		
362		3-way connection on rear axle for brake pi	Bolt to bracket	1	HZS0506		Hex screw	Zinc			5/16"	3/4"	UNF
363		3-way connection on rear axle for brake pi	Nut for bolt	1	FNZ 105		None-Lock nut	Zinc		Normal thickness & Strengt	5/16"		UNF
364		3-way connection on rear axle for brake pi	Spring washer	1	LWZ 105		Spring Washer	Zinc		Spring washer, heavy sectio	5/16"		
405		Bellerank lever on carburetter shield	Spring washer for stop pin	1	2K 1211	LWZ205					5/16"		
406		Bellerank lever on carburetter shield	Lockwasher for fulcrum and stop pins	1	2K 4945						5/16"		
407		Bellerank lever on carburetter shield	Plain washer	1	52K 1343						5/16"		
420		Clutch pedal lever, L.H. Steering	Washer	1	52K 1342	PWZ 105					5/16"		
421		Clutch pedal lever, L.H. Steering	Locknut for bolt	1	LNZ 305		Stiff nut or nyloc	Zinc		Castle nut, extra thick, norm	5/16"		UNF
422		lever, on shaft, for clutch connecting	Bolt, lever to shaft	1	HBZ0514		Hex bolt	Zinc			5/16"	1 3/4"	UNF
423		lever, on shaft, for clutch connecting	Washer for bolt	1	52K 1342	PWZ 105					5/16"		
424		lever, on shaft, for clutch connecting	Locknut for bolt	1	LNZ 305		Stiff nut or nyloc	Zinc		Castle nut, extra thick, norm	5/16"		UNF
425		Clutch connecting rod, non-adjustable	Washers	2	PWZ 105		Standard flat washer	Zinc		Standard washer, standard	5/16"		
428		Clutch connecting rod, adjustable	Washers	2	52K 1342	PWZ 105					5/16"		
429		Clutch connecting rod, adjustable	Adjusting nuts	2	1B 8749						5/16"		
430		Clutch connecting rod, adjustable	Locknuts	2	FNZ 205		None-Lock nut	Zinc		Lock nut, half thickness, no	5/16"		UNF
444		Push rod fork with extension for brake mas	Locknut, fork to push rod	1	2K 3916						5/16"		
445		Push rod fork with extension for brake mas	Washer for clevis pin	1	52K 1342	PWZ 105					5/16"		
446		Packing piece for master cylinder	Setscrews, master cylinder	2	52K 1514		Hex setscrew				5/16"	2 5/16"	
447		Packing piece for master cylinder	Spring washers	2	2K 5319	LWZ 205					5/16"		
451		Handbrake lever assembly	Setscrews to body	2	1B 8895		Slotted screw				5/16"	1 1/8"	
454		Fork for cable, balance lever end	Washer for pin	1	PWZ 105		Standard flat washer	Zinc		Standard washer, standard	5/16"		
455		Brake balance lever assembly	Bolts, support to bracket on axle	2	HZS0506		Hex screw	Zinc			5/16"	3/4"	UNF
456		Brake balance lever assembly	Nuts for bolts	2	FNZ 105		None-Lock nut	Zinc		Normal thickness & Strengt	5/16"		UNF
457		Brake balance lever assembly	Plain washers	2	PWZ 105		Standard flat washer	Zinc		Standard washer, standard	5/16"		
458		Brake balance lever assembly	Spring washers	2	LWZ 105		Spring Washer	Zinc		Spring washer, heavy sectio	5/16"		
464		Straps, tank to body	Spring washers	2	2K 1211	LWZ205					5/16"		
474		Radiator support brackets	Washers	4	52K 1342	PWZ 105					5/16"		
475		Radiator support brackets	Spring washers	4	2K 5319	LWZ 205					5/16"		
504		Hinge, L&R	Nuts. hinge to body	2	53K 1662		None-Lock nut	Zinc			5/16"		
505		Hinge, L&R	Plain washers	2	PWZ 105		Standard flat washer	Zinc		Standard washer, standard	5/16"		
518		Hood assembly	Nuts	6	FNZ 105		None-Lock nut	Zinc		Normal thickness & Strengt	5/16"		UNF
519		Hood assembly	Plain washers	6	PWZ 105		Standard flat washer	Zinc		Standard washer, standard	5/16"		
520		Hood assembly	Spring washers	6	LWZ 205		Spring Washer	Zinc		Medium weight spring wash	5/16"		
543		Hinges	Screws, hinges to body	16	51K 1138		Countersunk screw			Phillips	5/16"	1"	
586		Squab frame assemblies	Bolts, squab frame to cushion frame	4	HZS0509		Hex screw	Zinc			5/16"	1 1/8"	UNF
587		Squab frame assemblies	Dome nuts	4	14B 2685		Dome nut	Chrome			5/16"		
588		Squab frame assemblies	Plain washers	12	PWZ 105		Standard flat washer	Zinc		Standard washer, standard	5/16"		
589		Squab frame assemblies	Plain washers	4	PWP 105		Standard flat washer	Plain		Standard washer, standard	5/16"		
625		Steering column fixing bracket	Screws to retainer bracket	2	HNS0505		Hex screw	Plain			5/16"	5/8"	UNF
626		Steering column fixing bracket	Nuts for screws	2	FNN 105		None-Lock nut	Plain		Normal thickness & Strengt	5/16"		UNF
627		Steering column fixing bracket	Plain washers	4	PWN 105		Standard flat washer	Plain		Standard washer, standard	5/16"		
628		Steering column fixing bracket	Spring washers	2	2K 1211	LWZ205					5/16"		
629		Steering column fixing bracket	Screws for fixing bracket. channel end cold air duct panel	2	HNS0505		Hex screw	Plain			5/16"	5/8"	UNF

630		Steering column fixing bracket	Nuts for screws	2	FNN 105		None-Lock nut	Plain		Normal thickness & Strength	5/16"			UNF
631		Steering column fixing bracket	Plain washers	4	PWN 105		Standard flat washer	Plain		Standard washer, standard	5/16"			
632		Steering column fixing bracket	Spring washers	2	2K 1211	LWZ205					5/16"			
35		Rubber mountings with bolts, bottom	Nuts	8	2K 3978	FNZ 107					7/16"			
36		Rubber mountings with bolts, bottom	Lockwashers	2	2K 6106						7/16"			
37		Rubber mountings with bolts, bottom	Spring washers	4	2K 5896	LWZ 207					7/16"			
49		Connecting rods	Nuts for bolts, self-locking	8	1K 2811		Nyloc nut	Plain		Lock nut, high strength	7/16"			
50		Connecting rods	Spring washers	8	2K 5896	LWZ 207	Spring washer	Plain		Spring washer, heavy section	7/16"			
51		Connecting rods	Tab washers	8	AEK 126						7/16"			
109		Water pump spindle	Nut for spindle	1	2K 3987						7/16"			
110		Water pump spindle	Spring washer	1	2K 5861						7/16"			
111		Water pump spindle	Washer. fibre	1	2K 4976			Fiber			7/16"			
148		Mounting pillar on engine front plate	Nut, 7/16" B.S.F	1	1K 3978						7/16"			BSF
149		Mounting pillar on engine front plate	Spring washer	1	2K 5896	LWZ 207					7/16"			
265		Gear carrier with bearing caps	Nuts for bolts and stud	4	FNN 107		None-Lock nut	Plain		Normal thickness & Strength	7/16"			UNF
266		Gear carrier with bearing caps	Washers for nuts	4	ATC7084						7/16"			
267		Gear carrier with bearing caps	Spring washers	4	LWN 107		Spring Washer	Plain		Spring washer, heavy section	7/16"			
310		Steering side tube lever, L & R	Bolts, U.N.F. to swivel axles, 3.5" long	2	HBZ0728		Hex bolt	Zinc			7/16"	3 1/2"		UNF
311		Steering side tube lever, L & R	Bolts, U.N.F. to swivel axles, 3.25" long	2	HBZ0726		Hex bolt	Zinc			7/16"	3 1/4"		UNF
312		Steering side tube lever, L & R	Nuts for bolts	4	FNZ 507		None-Lock nut	Zinc		Normal thickness, high strength	7/16"			UNF
315		Side tubes with ends	Nuts for base pins, U.N.F.	4	FNZ 307		None-Lock nut	Zinc		Castle nut, extra thick, normal	7/16"			UNF
326		Trunnion links, upper	Nuts for fulcrum pins, U.N.F. thread	2	FNN 407		None-Lock nut	Plain		Castle nut, normal strength	7/16"			UNF
345		Front hub with studs	Nuts for studs	8	FNZ 507		None-Lock nut	Zinc		Normal thickness, high strength	7/16"			UNF
346		Front hub with studs	Spring washers	8	LWZ 207		Spring Washer	Zinc		Medium weight spring washer	7/16"			
373		Rear spring pins, top and front, UNF thread	Nuts for pins, U.N.F.	4	FNZ 107		None-Lock nut	Zinc		Normal thickness & Strength	7/16"			UNF
374		Rear spring pins, top and front, UNF thread	Washers	2	PWZ 107		Standard flat washer	Zinc		Standard washer, standard	7/16"			
375		Rear spring pins, top and front, UNF thread	Spring washers	4	LWZ 207		Spring Washer	Zinc		Medium weight spring washer	7/16"			
385		links for shock absorbers	Nuts. link pins to axle	2	FNZ 107		None-Lock nut	Zinc		Normal thickness & Strength	7/16"			UNF
386		links for shock absorbers	Spring washers	2	LWZ 107		Spring Washer	Zinc		Spring washer, heavy section	7/16"			
436		Lever for clutch operating shaft	Nut, U.N.F., L.H. Steering	1	FNZ 107		None-Lock nut	Zinc		Normal thickness & Strength	7/16"			UNF
67		Cylinder Head	Studs, for cylinder head, in cylinder block	11	6K 41						7/8"			
68		Cylinder Head	Nuts for studs	11	2K 6995						7/8"			
69		Cylinder Head	Washers	11	2K 1205	PWN 107					7/8"			
516		Boot stay	Plain washers, 9/32"	2	6K 9433						9/32"			
163	Bulkhead	Voltage regulator	Screws to dash	2	PMZ0320		Pan-head screw	Zinc		Philips	No. 10	1 1/4"		UNF
164	Bulkhead	Voltage regulator	Spring washer	2	LWZ 203		Spring Washer	Zinc		Medium weight spring washer	No. 10			
167	Bulkhead	Fuse block	Screws to dash	2	PMZ0307		Pan-head screw	Zinc		Philips	No. 10	7/16"		UNF
168	Bulkhead	Fuse block	Spring washer	2	LWZ 203		Spring Washer	Zinc		Medium weight spring washer	No. 10			
174	DASHBOARD	Combined oil pressure gauge and thermometer	Screw, clip to bonnet surround	1	CMZ0307	quantity?	Countersunk	Zinc	Philips		No. 10	7/16"		
175	DASHBOARD	Combined oil pressure gauge and thermometer	Nut for screw	1	FNZ 103	quantity?	None-Lock nut	Zinc		Normal thickness & Strength	No. 10			UNF
176	DASHBOARD	Combined oil pressure gauge and thermometer	Spring washer	1	LWZ 203	quantity?	Spring Washer	Zinc		Medium weight spring washer	No. 10			
181	Footwell	Starter solenoid switch	Setscrews, solenoid switch to body	2	PMZ0308		Pan-head screw	Zinc		Philips	No. 10	1/2"		UNF
182	Footwell	Starter solenoid switch	Spring washers	2	LWZ 203		Spring Washer	Zinc		Medium weight spring washer	No. 10			
185	Footwell	Dipper switch	Screws for dipper switch	2	PMZ0306		Pan-head screw	Zinc		Philips	No. 10	3/8"		UNF
190	Overdrive	Operating solenoid on OD	Setscrews to bracket	2	PMZ0308		Pan-head screw	Zinc		Philips	No. 10	1/2"		UNF
191	Overdrive	Operating solenoid on OD	Spring washers	2	LWZ 203		Spring Washer	Zinc		Medium weight spring washer	No. 10			
194	Bulkhead	Overdrive rotary throttle switch	Screws to dash	2	PMZ0308		Pan-head screw	Zinc		Philips	No. 10	1/2"		UNF
195	Bulkhead	Overdrive rotary throttle switch	Spring washers	2	LWZ 203		Spring Washer	Zinc		Medium weight spring washer	No. 10			
196	Bulkhead	Relay for overdrive	Screws to dash	2	PMZ0308		Pan-head screw	Zinc		Philips	No. 10	1/2"		UNF
197	Bulkhead	Relay for overdrive	Spring washers	2	LWZ 203		Spring Washer	Zinc		Medium weight spring washer	No. 10			
203	Body	Headlamps	Screws. headlamps to body	8	53K 2556	RPZ0310	Raised, countersunk, pointed	Zinc			No. 10	5/8"		UNF
204	Body	Headlamps	Nuts	8	1B 2805						No. 10			UNF
210	Body	Rear reflectors	Screws, mountings to body and reflector	6	PMZ0308		Pan-head screw	Zinc		Philips	No. 10	1/2"		UNF
391		Accelerator pedal with shaft, LH Steering	Screws. brackets to body	3	53K 1095		Recessed countersunk head	Zinc			No. 10			UNF
392		Accelerator pedal with shaft, LH Steering	Nuts	3	FNZ 103		None-Lock nut	Zinc		Normal thickness & Strength	No. 10			UNF
397		Control rod (U.N.F. threads), pedal shaft lever	Nuts, joints to levers and rod	3	FNZ 103		None-Lock nut	Zinc		Normal thickness & Strength	No. 10			UNF
398		Control rod (U.N.F. threads), pedal shaft lever	Spring washers	3	LWN 203		Spring Washer	Plain		Medium weight spring washer	No. 10			
403		Control rod (U.N.F. threads), relay lever to pedal	Nuts, ball joints to levers and rod	3	FNZ 103		None-Lock nut	Zinc		Normal thickness & Strength	No. 10			UNF
404		Control rod (U.N.F. threads), relay lever to pedal	Spring washers	3	LWN 203		Spring Washer	Plain		Medium weight spring washer	No. 10			
408		Control rod (U.N.F. threads), bellcrank lever	Nuts, ball joints to levers and rod	3	FNZ 103		None-Lock nut	Zinc		Normal thickness & Strength	No. 10			UNF
409		Control rod (U.N.F. threads), bellcrank lever	Spring washers	3	LWN 203		Spring Washer	Plain		Medium weight spring washer	No. 10			
413		Overdrive rotary switch lever, top	Bolt. lever to switch	1	52K 129						No. 10			UNF
414		Overdrive rotary switch lever, top	Plain washer	1	PWZ 103		Standard flat washer	Zinc		Standard washer, standard	No. 10			
415		Overdrive rotary switch lever, top	Nut	1	FNZ 103		None-Lock nut	Zinc		Normal thickness & Strength	No. 10			UNF
459		Springs, handbrake pull-off	Screws for clips	2	PMZ0306		Pan-head screw	Zinc		Philips	No. 10	3/8"		UNF

460	Springs, handbrake pull-off	Nuts for screws	2 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
461	Springs, handbrake pull-off	Spring washers	2 LWZ 203	Spring Washer	Zinc	Medium weight spring wash	No. 10		
476	Adaptor plate, L&R bonnet surround to cha	Screws, securing plates	4 51K 2636	Pan-head screw	Plain		No. 10	1/2"	UNF
477	Adaptor plate, L&R bonnet surround to cha	Nuts	4 FNN 103	None-Lock nut	Plain	Normal thickness & Strengt	No. 10		UNF
478	Adaptor plate, L&R bonnet surround to cha	Plain washers	8 PWN 203	Standard flat washer	Plain	Standard washer, large dia	No. 10		
479	Adaptor plate, L&R bonnet surround to cha	Spring washers	4 LWN 203	Spring Washer	Plain	Medium weight spring wash	No. 10		
480	Support bracket, bonnet surround, L&R	Screws, brackets, to support channels	4 51K 2636	Pan-head screw	Plain		No. 10	1/2"	UNF
481	Support bracket, bonnet surround, L&R	Nuts	4 FNN 103	None-Lock nut	Plain	Normal thickness & Strengt	No. 10		UNF
492	Front apron panel	Screws. No. 10. U.N.F. x 1/2", apron to cowl	2 53K 1096	Pan-head screw			No. 10	1/2"	UNF
493	Front apron panel	Nuts	2 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
494	Front apron panel	Washers	2 PWN 103	Standard flat washer	Plain	Standard washer, standard	No. 10		
495	Front apron panel	Spring washers	2 LWN 203	Spring Washer	Plain	Medium weight spring wash	No. 10		
496	Division panel, radiator to grille	Screws No. 10 U.N.F. X 1/2"	3 51K 2636	Pan-head screw			No. 10	1/2"	UNF
497	Division panel, radiator to grille	Nuts	3 FNN 103	None-Lock nut	Plain	Normal thickness & Strengt	No. 10		UNF
499	Division panel, radiator to grille	Spring washers	3 LWN 203	Spring Washer	Plain	Medium weight spring wash	No. 10		
506	Spare wheel retaining block	Screws to rear wheelarch	2 53K 3008				No. 10		
507	Spare wheel retaining block	Plain washers	2 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
508	Spare wheel breeching staple	Screws to axle cover panel	2 53K 2716				No. 10		
509	Spare wheel breeching staple	Nuts	2 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
510	Spare wheel breeching staple	Plain washers	2 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
525	Hood cover retainers (on rear top panel)	Plain washers	4 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
544	Reinforcement and attachment plates	Screws to "A" post	4 PMN0308	Pan-head screw	Plain	Philips	No. 10	1/2"	UNF
545	Reinforcement and attachment plates	Plain washers	4 PWN 103	Standard flat washer	Plain	Standard washer, standard	No. 10		
546	Reinforcement and attachment plates	Spring washers	4 LWN 203	Spring Washer	Plain	Medium weight spring wash	No. 10		
549	Hinge pillar brackets	Nuts	4 FNN 103	None-Lock nut	Plain	Normal thickness & Strengt	No. 10		UNF
551	Hinge pillar brackets	Spring washers	4 LWN 203	Spring Washer	Plain	Medium weight spring wash	No. 10		
556	Fascia and instrument panel	Screws to facia panel fixing bracket	4 PMP0310	Pan-head screw	Chrome	Philips	No. 10	5/8"	UNF
557	Fascia and instrument panel	Plain washers	4 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
559	Fascia and instrument panel	Nuts	4 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
573	Pedal hole blanking plate	Plain washers	2 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
574	Battery access panel assembly	Screws. hinges to panel	4 PMZ0306	Pan-head screw	Zinc	Philips	No. 10	3/8"	UNF
575	Battery access panel assembly	Nuts	4 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
576	Battery access panel assembly	Plain washers	4 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
577	Battery access panel assembly	Spring washers	4 LWZ 203	Spring Washer	Zinc	Medium weight spring wash	No. 10		
582	Asbestos covering, pedal box	Screws for asbestos panels	14 PMZ0310	Pan-head screw	Zinc	Philips	No. 10	5/8"	UNF
583	Asbestos covering, pedal box	Nuts	14 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
585	Asbestos covering, pedal box	Spring washers	14 LWN 203	Spring Washer	Plain	Medium weight spring wash	No. 10		
607	Gauze air valve	Screws. air valve to dash front panel	3 53K 2637	Pan-head screw		Philips	No. 10	7/16"	
608	Gauze air valve	Plain washers	3 6K 9695				No. 10		
609	Gauze air valve	Spring washers	3 2K 1209				No. 10		
610	Gauze air valve	Nuts	3 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
611	Flexible hose air intake	Screw, clip to wheelarch	1 PMZ0308	Pan-head screw	Zinc	Philips	No. 10	1/2"	UNF
612	Flexible hose air intake	Spring washer	1 LWZ 203	Spring Washer	Zinc	Medium weight spring wash	No. 10		
613	Flexible hose air intake	Plain washers	1 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
614	Flexible hose air intake	Nut	1 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
615	Cold air control bracket	Screws. fixing bracket	2 PMZ0310	Pan-head screw	Zinc	Philips	No. 10	5/8"	UNF
616	Cold air control bracket	Spring washers	2 LWN 203	Spring Washer	Plain	Medium weight spring wash	No. 10		
617	Cold air control bracket	Plain washers	4 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
618	Cold air control bracket	Nuts	2 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
619	Bracket for air valve control to dash	Screw to dash	1 53K 2634	Pan-head screw	Zinc	Philips	No. 10		
620	Bracket for air valve control to dash	Washers	2 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
621	Bracket for air valve control to dash	Nut	1 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
636	Blanking plates, heater tube holes	Screws, securing plates	2 PMZ0307	Pan-head screw	Zinc	Philips	No. 10	7/16"	UNF
637	Blanking plates, heater tube holes	Nuts	2 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
638	Blanking plates, heater tube holes	Spring washers	2 LWN 203	Spring Washer	Plain	Medium weight spring wash	No. 10		
639	Blanking plate, dipper switch hole	Screws	2 PMZ0310	Pan-head screw	Zinc	Philips	No. 10	5/8"	UNF
640	Blanking plate, dipper switch hole	Nuts	2 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
641	Blanking plate, dipper switch hole	Spring washers	2 LWZ 203	Spring Washer	Zinc	Medium weight spring wash	No. 10		
642	Blanking plate, dipper switch hole	Plain washers	2 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
647	Surround for grille	Nuts, fixing grille assembly	5 FNZ 103	None-Lock nut	Zinc	Normal thickness & Strengt	No. 10		UNF
648	Surround for grille	Spring washers	5 LWZ 203	Spring Washer	Zinc	Medium weight spring wash	No. 10		
649	Surround for grille	Plain washers	5 PWZ 103	Standard flat washer	Zinc	Standard washer, standard	No. 10		
655	Bonnet lock support bracket	Screws, bracket to dash front panel	3 51K 2637	Pan-head screw	Zinc	Philips	No. 10	5/8"	UNF
656	Bonnet lock support bracket	Nuts	3 FNN 103	None-Lock nut	Plain	Normal thickness & Strengt	No. 10		UNF
659	Tension spring retainer for bonnet catch	Screws	2 CMZ0308	Countersunk	Zinc	Philips	No. 10	1/2"	

660		Tension spring retainer for bonnet catch	Nuts	2	FNZ 103		None-Lock nut	Zinc		Normal thickness & Strengt	No. 10		UNF
662		Tension spring retainer for bonnet catch	Spring washers	2	PWZ 103		Standard flat washer	Zinc		Standard washer, standard	No. 10		
664		Fixing plates for leather stram (M models)	Screws for fixing plates	4	RMP0306		Raised, countersunk	Chrome		Philips	No. 10	3/8"	UNF
665		Fixing plates for leather stram (M models)	Nuts	4	FNZ 103		None-Lock nut	Zinc		Normal thickness & Strengt	No. 10		UNF
666		Fixing plates for leather stram (M models)	Spring washers	4	LWZ 103		Spring Washer	Zinc		Spring washer, heavy sectio	No. 10		
672		Lift dot fasteners in scuttle	Nuts	2	FNZ 103		None-Lock nut	Zinc		Normal thickness & Strengt	No. 10		UNF
673		Lift dot fasteners in scuttle	Plain washers	2	PWZ 103		Standard flat washer	Zinc		Standard washer, standard	No. 10		
548		Hinge pillar brackets	Screws, check straps to brackets	2	RMP0308		Raised, countersunk	Chrome		Philips	No. 11	1/2"	UNF
553		Door lock strikers	Screws	8	RMP0312		Raised, countersunk	Chrome		Philips	No. 12	3/4"	UNF
184	Dashboard	Panel light switch	Spring washers	2	LWZ 102		Spring Washer	Zinc		Spring washer, heavy sectio	No. 6		
186	Footwell	Dipper switch	Spring washers	2	LWZ 302		Spring Washer	Zinc		Spring washer, heavy sectio	No. 6		
187	Trunk	Battery master switch	Screws to body	2	PMZ0207		Pan-head screw	Zinc		Philips	No. 6	7/16"	UNF
188	Trunk	Battery master switch	Nuts	2	CNZ 102		None-Lock nut	Zinc		Normal thickness & Strengt	No. 6		UNF
189	Trunk	Battery master switch	Spring washers	2	LWZ 102		Spring Washer	Zinc		Spring washer, heavy sectio	No. 6		
206	Body	Side and blinker lamps, Stop and tail lamp	Screws, side and tail lamps to body	12	53K 2655		Pan-head screw				No. 6		UNF
207	Body	Side and blinker lamps, Stop and tail lamp	Nuts for screws	12	CNZ 102		None-Lock nut	Zinc		Normal thickness & Strengt	No. 6		UNF
309		Steering side and cross tube lever for stee	Washer	1	PWZ 102		Standard flat washer	Zinc		Standard washer, standard	No. 6		
522		Webbings, hood cover	Washers	4	6K 9062		Standard flat washer				No. 6		
606		Air (fresh) valve assembly	Screw	1	2K 4145		Screw, square head			slotted	No. 6	5/16"	
622		Ash tray	Screws, fixing ash tray	2	53K 1326			Zinc			No. 6		
623		Ash tray	Nuts	2	CNZ 102		None-Lock nut	Zinc		Normal thickness & Strengt	No. 6		UNF
624		Ash tray	Spring washers	2	2K 1369		Spring Washer	Zinc			No. 6		
No.	Comment	Part	Screw/Nut/Washer	Qty	Part No.	Commen	Type	Finish		Specification	Size	Length	Standard
4		Studs for main bearing caps	Nuts for studs, self-locking	6	1K 2812		Nyloc nut	Plain		Lock nut, high strength			
5		Studs for main bearing caps	Spring washers	6	2K 5949		Spring washer	Plain		Spring washer, heavy section			
6		front cover with oil catcher and felt	Setscrews, cover to crankcase	7	2K 3093		Hex setscrew						
19		Crankcase vent pipe with flange and clip	Setscrew, clip to crankcase	1	2K 3093		Hex setscrew						
21		Crankcase rear cover (half)	Setscrews, cover to crankcase	3	6K 502		Hex setscrew						
26		Engine rear plate	Setscrews for blanking off unused tapped holes in plate	2	2K 6146		Hex setscrew						
42		Camshaft gear	Nut for camshaft	1	2K 7681								
43		Camshaft gear	Lockwasher	1	1B 1219								
44		Driving pulley for fan and dynamo	Nut	1	1B 1061								
45		Driving pulley for fan and dynamo	Lockwasher	1	2H 131								
46		Flywheel with starter gear	Bolts to crankshaft	4	2K 6562								
47		Flywheel with starter gear	Lockwashers	2	2K 7552								
48		Connecting rods	Bolts with peg	8	1K 2808								
54		Oil pump body with pin	locating screw	1	1K 120								
55		Oil pump body with pin	Cap nut	1	1K 714								
56		Oil pump body with pin	Washer, fibre	1	2K 6958								
61		Oil reservoir (pan)	Setscrews with captive washer	20	6K 100		Hex setscrew						
62		Oil reservoir (pan)	Setscrew, long (5th from front of crankcase, left hand side	1	2C 1363		Hex setscrew						
65		Oil reservoir (pan)	Setscrew, centre rear	1	2K 8425		Hex setscrew						
66		Oil reservoir (pan)	Fibre washer, centre rear	1	2K 6337								
75		Valve rocker cover with oil filler cap	Studs	2	2K 7974								
76		Valve rocker cover with oil filler cap	Cap nuts	2	1B 2463								
80		Carburetter adaptor	Studs, carburetter to adaptor	4	2K 3499								
81		Carburetter adaptor	Studs, balance pipe flange to adaptor	4	2K 3403								
82		Carburetter adaptor	Studs, heater pipe clip to adaptor	2	2K 3446								
105		Water pump assembly	Studs in cylinder	3	2K 6065								
106		Water pump assembly	Nuts (shouldered) for studs, manifold	2	1D 105								
112		Vane for spindle	Nut	1	2K 4057								
118		Blanking plate for mechanical petrol pump	Collars for studs	2	2K 9631								
138		Dynamo	Nut, shaft	1	7H 5023								
139		Dynamo	Bolt, through fixing	2	17H 5180								
140		Dynamo	Bolt to bracket, front	1	2K 6563								
141		Dynamo	Bolt to bracket, rear	1	2K 5265								
144		Dynamo bracket	Studs, bracket to crankcase	4	6K 440								
145		Dynamo bracket	Nuts for studs	4	6K 280								
147		Dynamo bracket	Shakeproof washers	4	6K 441								
151		Adjusting link for dynamo	Washer	1	2K 9932								
152		Distributor with vacuum control	Setscrew, fixing plate to crankcase	1	2K 3046		Hex setscrew						
155		Vacuum ignition control pipe	Setscrew to cylinder head	1	2K 6146		Hex setscrew						
156		Driving spindle for distributor	Setscrew for bush	1	2K 3046		Hex setscrew						
158		Starter	Bolts, starter to gearbox	2	2C 1014								
165	Bulkhead	Fuse block											

166	Bulkhead	Fuse block	Screws, terminal	4	17H 5590	
169	rear axle	Battery	Fixing rods, U.N.F. thread	4	1B 2906	
170	rear axle	Battery	Washers	4	1B 2907	
171	rear axle	Battery	Washers	4	2K 9420	
172	rear axle	Battery	Spring washer	4	2K 2543	
183	Dashboard	Panel light switch	Screws panel light switch to dash ...	2	6K 9588	
192	Overdirve	Operating solenoid on OD	Special screw, plunger to lever	1	7H 5896	
193	Overdirve	Operating solenoid on OD	Split pin for screw	1	CPS 0205	
201	Frame	Harness cable clip screws	???	40	various	
202	Body	Headlamps	Screws for rims	2	AJA5081	Chrome
246		Coupling flange	Slotted nut for flange	1	7H 5889	
248		Speedometer pinion assembly	locking screw	1	7H 5894	
250		Speedometer pinion assembly	Copper washer for screw	1	17H 5834	
260		Engine tie rod	Washers	2	1B 8811	
261		Engine tie rod	Shakeproof washers	2	2K 7131	
264		Gear carrier with bearing caps	Bolts for bearing caps	4	ATC7083	
269		Gear carrier with bearing caps	bolts, in axle case, for carrier	12	ATC7125	
272		Bevel pinion	Bolts, crown wheel to differential case	10	ATA7043	
273		Bevel pinion	Lockwashers for bolts	5	ATC7109	
277		Rear hubs with bolts	Bolts for hub extensions (U.N.F.)	10	ATC1257	
278		Rear hubs with bolts	Conical locknuts, hub extensions to hubs (U.N.F.)	10	ATB7198	
279		Ball journal bearings for hubs	Nut for bearing, right hand thread	1	ATC1062	
280		Ball journal bearings for hubs	Nut for bearing, left hand thread	1	ATC7309	
281		Ball journal bearings for hubs	Lockwashers	2	ATC7310	
288		Steering column steady clamp halves	Bolt, short, for clamp	1	52K 1551	
289		Steering column steady clamp halves	Nut for bolt	1	52K 301	
292		Steering column steady clamp halves	Nut for bolt	1	52K 302	
294		Steering box clamping and mounting brack	Bolts to chassis frame, long	2	2K 8657	
295		Steering box clamping and mounting brack	Bolt to chassis frame, short	1	2K 8962	
296		Steering box clamping and mounting brack	Nuts for bolts	3	2K 3911	
302		Steering side and cross tube lever for stee	Nut castellated, lever to shaft, 3/4" U.N.F.	1	51K 370	
308		Steering side and cross tube lever for stee	Nut castellated, lever to shaft, 3/4" U.N.F.	1	51K 370	
313		Steering side tube lever, L & R	Lockwashers	2	1B 4451	
314		Side tubes with ends	Nuts for ball pins	4	2K 3996	
316		Cross tube with ends	Locknut, right hand thread	1	51K 320	
317		Cross tube with ends	Locknut, left hand thread	1	51K 365	
331		Fulcrum pins, inner links to frame	Nuts for fulcrum pins	4	2K 3991	
332		Fulcrum pins, inner links to frame	Special washers	4	1A 4785	
341		Anti-roll bar	Setscrews for straps	4	52K 2036	Hex setscrew
343		Swivel axles	Nuts. U.N.F.	2	51K 330	
344		Swivel pins with fulcrum pin for lower links	Nuts castellated (top) for swivel pins, U.N.F.	2	51K 329	
347		Brake backplate	Setscrews to swivel axles, U.N.F.	4	1B 4454	Hex setscrew
348		Brake backplate	Lockwashers	2	1B 4457	
349		Steady posts	Locknuts	4	7H 4991	
352		Flexible brake hose	Copper washers for hoses	3	3H 870	
353		Flexible brake hose	Shakeproof washers	3	2K 7131	
367		Rear springs	Toe bolts	2	2A 5006	
390		Rear axle tie rod	Locknuts for tie rod ends	2	53K 1393	
419		Clutch pedal lever, L.H. Steering	Bolt, clutch pedal to shaft	1	52K 30	
426		Clutch relay lever	Washer	1	1B 8806	
427		Clutch relay lever	Locknut	1	53K 1393	
432		Clutch housing with bushes	Dowel bolts	2	2K 7717	
435		Clutch operating shaft, L.H. Steering	Washer	1	2K 8133	
437		Lever for clutch operating shaft	Washer	1	1B 3321	
438		Lever for clutch operating shaft	Shakeproof washer	1	2K 3072	
452		Handbrake cable assembly	Locknut for outer cable abutment bracket	1	1B 1364	
462		Straps, tank to body	Nuts for "T" bolts on straps	2	2K 3916	
463		Straps, tank to body	"D" washers for "T" bolts	2	14B 2036	
465		Radiator with filler cap	Setscrews, radiator to support brackets	2	2K 3048	Hex setscrew
472		Radiator support brackets	Bolts, support brackets to frame brackets	4	52K 2036	
473		Radiator support brackets	Nuts for bolts	4	52K 302	
484		Front wing assembly, L&R	Bolts. outer, to inner wings	10	14B 2025	
485		Front wing assembly, L&R	Spire nuts	10	6K 9817	
500		Hinge, L&R	Seating washers. male	2	14B 3462	
501		Hinge, L&R	Seating washers. female	2	14B 3463	

517	Hood assembly	Screws, hood to rear quarter inner panel	6 53K 1138		
521	Webbings, hood cover	Screws	4 54K 3014		
523	Hood cover retainers (on rear top panel)	Screws to rear top panel	4 53K 2635		
524	Hood cover retainers (on rear top panel)	Cap washers	4 2K 9798	Cup washer	
527	Hood stick retainers	Woodscrews (chrome head) to hood stick	6 5C 7169		
528	Hood toggle fastener assembly, L&R	Screws to frame	4 54K 2557		
529	Hood toggle fastener assembly, L&R	Plain washers	4 6K 9562		
530	Hood toggle fastener assembly, L&R	Dome nuts	4 14B 1997		
531	Hood toggle fastener assembly, L&R	Dome nuts on toggle fasteners	4 14B 5683		
533	Hood toggle fastener assembly, L&R	Washers	4 54K 3177		
534 to B.5000	Hinges	Screws. 1" long	12 51K 1228		1"
535	Hinges	Screws. 3/4" long	4 51K 1226		3/4"
536	Hinges	Screws	20 51K 1223		
540 B.5001 on	Hinges	Brass washers	16 2K 9020		
541	Hinges	Screws. 1" long	8 51K 1138		1"
542	Hinges	Screws. 3/4" long	8 51K 1136		3/4"
547	Hinge pillar brackets	Screws. brackets to hinge pillars	4 51K 1097		
552	Door lock, L&R	Screws for lock catch plates	2 54K 3014		
554	Securing strip for door to scuttle seal	Screws. self-tapping	14 6K 9713		
555	Securing strip for door to scuttle seal	Screws. attachment brackets to hinge pillars	6 PTZ 803		
560	Cockpit moulding	Screws fixing mouldings	22 6K 9924		
564	Shut pillar face cover plate (aluminum)	Screws fixing cover plates	12 6K 9671		
565	Sill panel cover plate (aluminum)	Screws fixing cover plates	12 6K 9671		
566	Gearbox cover assembly	Screw, securing oil filler plate	1 54K 2777		
567	Gearbox cover extension panel	Screw, gearbox cover to floor	8 PTZ 806		
568	Gearbox cover extension panel	Screws, gearbox cover to extension panel	3 PTZ 308		
569	Gearbox cover extension panel	Screws, gearbox cover extension panel to pedal box	6 RTZ 806		
570	Steering column blanking plates	Screws	16 53K 2992		
571	Steering column blanking plates	Plain washers	16 53K 3157	Flat washer	Large washer
572	Pedal hole blanking plate	Screws to floor	2 53K 2635		
584	Asbestos covering, pedal box	Plain washers	14 53K 3151		
633	Grab handle	Nuts. securing handle	2 52K 301		
646	Surround for grille	Self tapping screws, radiator grille to surround	12 PTZ 602		
650	Surround for grille	U type claw washers	5 14B 4570		
663	Prop rod retainer bracket	Screws to bonnet top	2 6K 9713		
671	Side stanchion and front assembly, L&R	Screws	8 51K 2375		

From Publication AKD870

Courtesy

Tadeusz Malkiewicz
